



CINCH PLUG IN = BOOSTER  
CINCH PLUG OUT = COMMAND STATION

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED

DCC SETUP FOR GRVS				
SIZE B	FSCM NO.	DWG NO.	DCC_SETUP.DWG	REV 1
SCALE NA			SHEET DCC_SETUP	